

WFX-600 THRU WFX-2400 DETAIL

WALL-TO-WALL EXTERIOR CONDITION

() - Denotes Millimeters

DIMENSION CHART					
MODEL	"A" @ MIN.	"A" @ MID.	"A" @ MAX.	"B"	TOTAL MOVEMENT
WFX-600	2-1/4"(57)	6"(152)	12"(300)	13-1/2"(343)	9-3/4"(248)
WFX-800	2-1/4"(57)	8"(203)	16"(400)	17-1/2"(445)	13-3/4"(349)
WFX-1000	2-3/4"(70)	10"(254)	20"(508)	21-1/2"(546)	17-1/4"(438)
WFX-1200	3"(80)	12"(305)	24"(600)	25-1/2"(648)	21"(534)
WFX-1800	3"(80)	18"(457)	36"(900)	37-1/2"(953)	33"(800)
WFX-2400	3"(80)	24"(610)	48"(1200)	49-1/2"(1257)	45"(1100)

Note: Minimum And Maximum Values Are After Movement Occurs. Mid Point Value Is The Recommended Size Of Opening At Installation.

Exterior Wall

Wabo®SeismicCover



Watson Bowman Acme Corp. 95 Pineview Drive Amherst, NY 14228 phone: (716) 691-7566 fax: (716) 691-9239 www.wbacorp.com

BASF
The Chemical Company

Information provided herein, including but not limited to, any drawing, design, photograph, graphic, or statement(s) ("Materials") are proprietary and the property of Waters Bowman Acme Corporation ("Company"). Reproduction, translation, or reduction to any electronic medium or machine readable form, in whate or part, it stictly prohibidine, coaspit for the express purpose for which it has been furnished, withour plor withen consent of Company. All Materials contained herein are provided by Company for Information purposes only. Company reserves the right to amend or withdraw any information contained in the Materials without notice. All technicals or other advice by Company, whether verball or written, concerning products, or the use of products in specific stateations. ("Advice") is given by Company and is used at the Users own this